

Schu-Tone Luna Obscura

(+9v power only, current draw 335mA)

Delay

Delay - Sets Delay time
Mix - Controls amount of delay signal
Swell - Adjusts amount of repeats
Heads - Adds delay heads (1 is shortest, 4 is longest, use any combination of heads) vibrato

Vibe


Speed - Sets the speed of Vibe
Depth - Controls intensity of vibe
Volume - Sets overall level of vibe signal
Chorus/Vibrato - Adds dry signal for chorus mode, removes for vibrato

Boost

Volume - Sets overall volume of boost
Drive - Controls amount of gain in boost
Treble - Cuts or Boosts high end
Bass - Cuts or Boosts low end

Fuzz

Volume - Sets overall volume of fuzz
Fuzz - Controls amount of fuzziness of signal
Brite - Adjusts the high-end of fuzz tone
Body - Controls the amount of thickness of fuzz sound



Jacks

In - Input from Guitar
+9V - +9VDC Power
Send - Effects loop send to add other effects post-boost
Return - Effects loop return
EXP - TRS Jack for expression pedal control of Vibe Speed
Out - Output to amp